



E-1 CRANKCASE ASSY.




1		Drain plug	
2		Washer	
3	990723	Bearing 6205	
4	990730	Oil seal, crankshaft	
5	990630	Crankcase	
6		Regulating sway bar	
7		Washer	
8		Split pin	
9		Nut M10	
10	990690	Oil sensor	
11		Bolt M6×14	
12		Regulating shaft	
13		Washer, driven gear	
14		Pin	
15		Driven gear, regulator	
16		Flying block	
17	990710	Driven gear assy, regulator	
18		Snap ring	
19		Washer	
20		Sliding sleeve	
21		Clip	
22		Diode	

E-2 CRANKCASE COVER ASSY.


1	990776	Oil plug with Seal	
2		Oil plug	
3		Seal	
4	990650	Crankcase cover	
5	990723	Bearing 6205	
6	990700	Gasket, crankcase	
7		Set pin	
8		Dipstick	
9	990770	Dipstick with seal	
10	990731	Oil seal, crankshaft	
11		Bolt M6x28	

E-3 CYLINDER HEAD & CYLINDER HEAD COVER ASSY




1		Bolt M6×12	
2		Air duck	
3		Lead wind cover	
4		Stud M6×113	
5	990380	Set pinφ10×16	
6	990370	Gasket, cylinder head	
7	990430	Cylinder head Assy	
8	990410	Stud M8×34	
9	990420	Spark plug F6TC	
10		Bolt M8×55	
11	990360	Gasket, cylinder head cover	
12	990350	Cylinder head cover Assy	

E-4 CRANKSHAFT, PISTON & CONNECTING




1		Piston ring (I)	
2		Piston ring (II)	
3		Side rail	
4		Expander	
5		Scraper ring set	
6	990550	Piston ring assy	
7	990560	Piston pin circlip	
8	990570	Piston	
9	990580	Piston pin	
10		Shank	
11		Bolt	
12	990590	Connecting rod assy	
13		Woodruff key	
14		Drive gear	
15		Crankshaft	
16		Timing driving gear	
17	990600	Crankshaft assy	

E-5 COMBINATION OF CAM SHAFT & VALVE ROCKER


1		Lock nut	
2		Sleeve	
3		Valve rocker	
4		Adjusting bolt for valve gap	
5	990440	Valve rocker assy	
6	990450	Pusher guide	
7	990460	Pusher	
8	990470	Tappet	
9		Extension spring	
10	990480	Camshaft Assy	
11	990490	Exhaust valve	
12	990500	Intake valve	
13	990510	Valve spring	
14	990520	Spring seat, intake valve	
15	990530	Spring seat, exhaust valve	
16	990540	Cap	

E-6 CARBURETOR ASSY




1	990240	Inlet gasket	
2	990250	Connecting block	
3	990260	Carburettor gasket	
4		Idle adjustment screw	
5		Mixture chamber body	
6		Main nozzle	
7		Main jet	
8		Float	
9		Float chamber gasket	
10		Float chamber	
11		Washer	
12		Float chamber drain Screw	
13		Screw	
14	990270	Air cleaner gasket	
15		Choke	
16		Choke stem	
17		Airproof washer	
18		Throttle lever	
19		Washer	
20		Screw M4	


E-6 CARBURETOR ASSY




21		Cover	
22	990290	Choke switch	
23		Throttle unit	
24		Spring, mixture adjustment screw	
25		Mixture adjustment screw	
26		Choke unit	
27		Float chamber	
28	990300	Carburettor Assy	
29		Float needle	

E-7 FUEL TANK ASSY


1		Pipe clamp	
2		Outlet pipe	
3		Bolt M6×22	
4		Packing ring	
5	990020	Connector	
6		Nut M6	
7		Filter cup	
8		Packing ring	
9		Fuel filler cap	
10	990010	Fuel filler cap with packing ring	
11	990001	Fuel tank	

E-8 AIR CLEANER ASSY

1	990030	Wing nut	
2		Air cleaner top cover sub-assy	
3		Air cleaner cover	
4	990040	Filter element	
5		Bracket, filter element	
6		Bolt M6x25	
7		Bolt M4x12	
8		Air cleaner base	
9		Gasket, air cleaner seat	
10		Air cleaner housing assy	
11		Nut M6	
12	990050	Air cleaner assy	


E-9 MUFFLER

1		Screw M5x8	
2		Muffler hood	
3		Nut M8	
4		Muffler	
5	990080	Exhaust muffler	
6	990060	Exhaust gasket	
7		Washer	


E-10 RECOIL STARTER

1		Bolt M6×16	
2		Crankcase side plate assy	
3	990100	Bolt M6×8	
4		Fan hood assy	
5	990102	Bolt M6×12	
6	990110	Engine switch	
7		Casing	
8	990120	Spiral spring	
9	990121	Ratchet spring	
10	990125	Ratchet	
11	990122	Friction spring	
12	990126	Spring lid	
13	990103	Set screw	
14	990130	Starter rolls	
15		Rope	
16	990108	Pulling handle	
17	990140	Recoil starter	
18	990150	Recoil starter assy	


E-11 REGULATING CONTROLS SYSTEM



1		Nut M6	
2		Setting panel	
3		Spring patch	
4		Handgrip	
5		Washer	
6		Bolt M5×16	
7		Clamp	
8		Bolt M5×25	
9		Regulating spring	
10		Support panel Assy	
11		Spring	
12	990160	Back spring	
13	990170	Fine Regulating spring	
14	990180	Pulling rod	
15		Lock bolt	
16		Regulating arm	
17	990190	Regulating frame assy	

E-12 FLYWHEEL

1	990200	Flywheel	
2	990210	Flywheel fan	
3	990220	Starting flange	
4	990230	Flywheel Nut	

E-13 IGNITION COIL

1		Screw M6×22	
2		Engine stop cable	
3		Ignition coil	
4		Spark plug cap	
5	990670	Ignition coil assy	