




E-1 CRANKCASE ASSY.

1	990637	Crankcase	
2	990691	Oil sensor	
3		Regulating sway bar	
4		Drain plug	
5		Washer	
6	990734	Oil seal, crankshaft	
7		Washer	
8		Split pin	
9		Bolt M6×12	
10	990721	Bearing 6202	
11	990680	Diode	
12		O-ring 13×1.4	
13		Nut M10	
14		Oil seal, regulating sway bar	

E-2 CRANKCASE COVER ASSY.


1	990656	Crankcase cover	
2		Guard,crankcase cover	
3	990703	Gasket, crankcase	
4	990772	Dipstick	
5	990712	Driven gear set, regulator	
6		Flying block	
7		Driven gear, regulator	
8		Pin	
9		Sliding sleeve	
10		Bolt M5×12	
11		Snap ring	
12		Set pin	
13	990734	Oil seal , crankshaft	
14		Seal	
15		Washer, driven gear	
16		Bolt M8×40	
17	990721	Bearing 6202	
18	990725	Bearing 6207	
19		Regulating shaft	
20		Washer, sliding sleeve	

E-3 CYLINDER HEAD & CYLINDER HEAD COVER ASSY




1	990433	Cylinder head Assy	
2	990368	Rubber seal	
3		Washer	
4		Bolt	
5	990374	Gasket, cylinder head	
6	990350	Cylinder head cover Assy	
7	990361	Gasket, cylinder head cover	
8	990410	Stud M8x35	
9		Bolt	
10	990404	Stud M6xM8x106	
11	990381	Set pin	
12		Flange bolt	
13	990420	Spark plug F6TCU	
14		Lead wind cover	
15		Bolt M6x12-F	
16	990365	Oil seal, valve stem	

E-4 CRANKSHAFT, PISTON & CONNECTING




1		Piston ring (I)	
2		Piston ring (II)	
3		Side ring	
4		Wave ring	
5		Scraper ring set	
6	990577	Piston	
7	990583	Piston pin	
8		Connecting rod Assy	
9		Bolt	
10	990562	Piston pin circlip	
11	990725	Bearing 6207	
12		Woodruff key	
13		Drive gear	
14		Timing driving gear	
15	990608	Crankshaft sets	
16	990620	Balancing shaft	
17	990593	Connecting rod	
18	990557	Ring Set	

E-5 COMBINATION OF CAM SHAFT & VALVE ROCKER




1		Lock nut	
2		Sleeve	
3		Valve rocker	
4		Adjusting bolt for valve gap	
5	990452	Pusher guide	
6	990463	Pusher	
7	990472	Tappet	
13	990482	Camshaft Assy	
14	990503	Intake valve	
15	990493	Exhaust valve	
16	990512	Valve spring	
17	990523	Spring seat, exhaust valve	
18	990523	Spring seat, intake valve	
19	990541	Cap, exhaust valve	
20		Spring retainer, exhaust valve	
21	990441	Valve rocker Assy	
22		Limit position panel	
23		Pin	
24	990533	Cone For Valve	

E-6 CARBURETOR ASSY




1	990281	Gasket ,float chamber
2		Float needle
3		Float
4		Float chamber
5		Mixture adjustment screw
6		Drain screw, float chamber
7		Screw
8	990307	Carburettor Assy
9		Idle adjustment screw
10		Dust cover, choke
11		Pipe, main jet
12		Spring, mixture adjustment screw
13	990254	Connecting block, carburettor
14	990263	Gasket, carburettor
15	990242	Gasket, inlet
16		Magnetic valve, carburettor
22		Stopper, choke rod
23		Spring, choke
24	990271	Gasket, air cleaner
27		Rubber washer, choke lever 1
28		Rubber washer, choke lever 2

E-7 Kick Starter




1	990142	Kick starter	
2		Casing	
3	990132	Starting roller	
4	990125	Ratchet	
5	990126	Spring lid	
6	990122	Friction spring	
7	990123	Spiral spring	
8	990121	Spring, ratchet	
9	990108	Handle	
10		Rope	
11	990103	Set screw	
12	990100	Screw M6x8	
13		Wire clamp B	
14		Grommet	
15		Fan case	
16	990102	Screw M6x12	
17		Recoil starter assy	

E-8 Regulating Control System




1		Regulating arm	
2		Pulling rod	
3		Back spring	
4	990172	Fine regulating spring	
5	990195	Supporting plate set	
6		Supporting plate	
7		Regulating spring	
8		Bolt M6×12	
9		Lock bolt	
10		Screw M5×35	
11		Nut M6	

E-9 Flywheel


1	990213	Flywheel fan	
2	990223	Starting flange	
3	990231	Nut M16×1.25	
4	990204	Flywheel	

E-10 Ignition Coil




1		Ignition coil	
2		Spark plug cap	
3		Clamper, cord	
4		Rubber ring, crankcase	
5	990755	Charge coil	
6		Extinguishing cable	
7		Cable tie	
8		Bolt M6×12	
9		Bolt M6×35	
10		Bolt M6×30	
11	990672	Ignition coil unit	

E-11 Air Cleaner Assy




1		Air duck	
2		Gasket, air cleaner	
3	990045	Filter element	
4		Retainer, filter element	
5		Air cleaner case	
6		Air cleaner stay	
7		Air cleaner cover	
8		Hinge	
9		Gasket	
10		Boot, vent pipe	
11		Nut M5	
12		Nut M6	
13	990055	Air cleaner Assy	

E-12 Muffler ASSY


1	990085	Muffler	
2	990091	Outer hood	
3	990092	Side hood	
4	990093	Inner hood	
5		Gasket, inner hood	
6	990072	Exhaust pipe	
7	990067	Gasket, exhaust pipe	
8	990062	Gasket, outlet	
9		Muffler stay	
10		Flange bolt M8×25	
11		Nut M8	
12		Flange bolt M6×12	
13		Flange bolt M8×16	

E-13 Fuel Tank Assy




1	990021	Fuel cock	
2	990005	Fuel tank	
3		Stripe, fuel tank	
4	990011	Fuel filler cap comp.	
5		Fuel sensor	
6		Packing ring	
7		Fuel filler	
8		Washer	
9		Cushion	
10		Grommet	
11		Fitting brush, fuel tank	
12		Screw M5×10	
13		Outlet pipe (φ9×φ4.5×160)	
14		Tube clip	
15		Flange bolt M6×22	
16		Gasket, fuel sensor	

E-14 Starting Motor Assy




1		Relay, start-up	
2		Rotor comp.	
3		Starting clutch	
4	990750	Starting motor Assy	
5		Base, starting	
6		Housing, starting clutch	
7		Driven gear	
8		Brush comp.	
9		Stator Assy	
10		Spring, brush	
11		Reducing gear	
12		Stay, brush	
13		Cable, starting motor	
14		Insulator	
15		Bolt M5×14	
16		Screw M4×6	

G-01 Control Panel




1		Earth terminal set	
2		Boot, AC output wire	
3		Boot, main wire harness	
4		Boot, switch wire	
5	991040	Diode Assy	
6		Main wire harness Assy	
7		Spring washer 6mm	
8	991000	Consent (30A)	
9		Bolt M4×10	
10	991062	Control panel Assy	
11		Control panel	
12		Control panel case	
13		Panel switch mark,RH	
14	990112	Ignition switch	
15		Key	
16	991021	Voltmeter	
17	991032	Circuit protector, 23A	
18		Panel switch mark,LH	
29		Fuse case	
30		Fuse (10A)	
31	991041	Regulator	

G-02 Generator



1		Connecting plate	
2	991072	Stator Assy	
3		Stator cover	
4	991082	Rotor Assy	
5	990666	Generator stay	
6	991111	Generator end cover	
7	991115	Generator fan	
8	991091	Brush Assy	
9	991051	Voltage regulator	
10		Bolt M10×265	
11		Screw M5×18	
16		Spring washer 5mm	
17		Bolt M6×175	
18		Plain washer	
19		Clip A	
20		Plug, sump	
21		Bearing 6204-2ZN	
22		Nut M5	
23		Nut M5	
24		Washer 5mm	

G-03 Frame

1		Frame comp.	
2	991102	Bottom rubber A	
3	991103	Bottom rubber B	
4		Nut M10	
5		Nut M6	
6		Cushion, frame	
7		Bolt M6×12	
8		Rubber pad, frame	
9		Nut M8	