

UNIVERSAL

H A R D W A R E[®]



MOTORCYCLE PARTS CATALOGUE

Model: **LF150-5U KP Mini**

Spanish Lookout
sales@universalhardware.bz
☎ +501 823 0254 📞 +501 652-9933

Belize City
salesbz@universalhardware.bz
☎ +501 224-4140 📞 +501 667-3937

2025



Model: **LF150-5U**



Model: **LF250GY-4**



Model: **ML125-16D Flash**



Model: **LF150-5L**



Model: **ML250GY-4**



Model: **ML200ZH-3**



Model: **ML200GY-4**



Model: **LF100-A**



Model: **LF110-7A NINJA**



Model: **LF200GY-4**



Model: **LF125-5**



Model: **LF125-7**



Model: **LF150T-12C**



Model: **LF150-7 Retro**



Model: **LF200-14F**

F-01 灯具 LIGHTS



	1505211-1	Headlight Hood	
	1505211-2	Headlight Assy	
	1505211-3	Front Winker, LH	
	1505211-4	Front Winker, RH	
	1505211-5	Rear License Light	
	1505211-6	Taillight Assy	
	1505211-7	Bulb	
	1505211-8	Bulb	

F-02 仪表 拉索 METER & CANLE



	1505212-1	Meter Case	
	1505212-2	Meter Assy	
	1505212-3	Throttle Cable	
	1505212-4	Choke Cable	
	1505212-5	Clutch Cable	

F-03 方向把 手把开关 STEERING BAR & SWITCH



	1505213-1	Steering Bar Pipe Comp.	
	1505213-2	Grip,LH	
	1505213-3	Throttle Grip Comp.	
	1505213-4	Handlebar Switch,LH	
	1505213-5	Handlebar Switch,RH	
	1505213-6	Clutch Lever Comp.	
	1505213-7	Clutch Lever	
	1505213-8	Rearview Mirror,LH	
	1505213-9	Rearview Mirror,RH	
	1505213-10	Front Disc Brake Pad	
	1505213-11	Front Brake Switch	
	1505213-12	Front Brake Lever	
	1505213-13	Front Hydraulic Brake Assy	
	1505213-14	Front Brake Disc	

F-04 方向柱组合 STEERING STEM




	1505214-1	Steel Ball 4.762	
	1505214-2	Bottom Bearing Bottom Ball Race	
	1505214-3	Top Bearing Bottom Ball Race	
	1505214-4	Top Bearing Bottom Ball Race	
	1505214-5	Top Bearing Top Ball Race	
	1505214-6	Steering Stem Assy	
	1505214-7	Steering Stem	
	1505214-8	Adjusting Nut, Steering Stem	
	1505214-9	Adjusting Washer, Steering Stem	
	1505214-10	Cap Nut	
	1505214-11	Top Steering Stem Connection Board Comp.	
	1505214-12	Steering Bar Holder	
	1505214-13	Top Steering Stem Connection Board	
	1505214-14	Steering Bar Clamp	

F-05 前挡泥板 FRONT FENDER



	1505215-1W	Front Fender	
	1505215-2	Stay Comp, Front Brake Hose	

F-06 减震器 SHOCK ABSORBER



	1505216-1	Front Shock Absorber, RH	
	1505216-2	Front Shock Absorber, LH	
	1505216-3	Rear Shock Absorber Assy	



	1505217-1	Front Tyre	
	1505217-2	Front Wheel Hub Comp.	
	1505217-3	Speedometer Sensor	
	1505217-4	Front Wheel Right Bush	
	1505217-5	Front Axle	
	1505217-6	Tube Valve	

F-08 后轮总成 REAR WHEEL ASSY




	1505218-1	Rear Tyre	
	1505218-2	Rear Wheel Rim Comp.	
	1505218-3	Rear Hydraulic Disc Brake	
	1505218-4	Rear Wheel Bush, RH	
	1505218-5	Rear Axle	
	1505218-6	Rear Wheel Bush LH	
	1505218-7	Sprocket	
	1505218-8	Sprocket Kahuang 48-Cr mc	
	1505218-9	Sproket Bolt	
	1505218-10	Rear Tube Valve	
	1505218-11	Rear Brake Disc	
	1505218-12	Rear Brake Shoe	

F-09 搁脚组合 FOOTREST



	1505219-1	Rider Footrest Assy	
	1505219-2	Front Footrest Rubber Sleeve	
	1505219-3	Side Stand Comp.	
	1505219-4	Spring, Side Stand	
	1505219-5	Shoulder Bolt	
	1505219-6	Rear Brake Pedal Comp.	
	1505219-7	Rear Brake Pedal Bush	
	1505219-8	Rear Brake Pedal Torsion Spring	
	1505219-9	Passenger Footrest Ornament Comp., RH	
	1505219-10	Passenger Footrest Stay Comp., RH	
	1505219-11	Passenger Footrest Ornament Comp., LH	
	1505219-12	Passenger Footrest Stay Comp., LH	
	1505219-13	Passenger Footrest Comp., RH	
	1505219-14	Passenger Footrest Comp., LH	
	1505219-15	Rear Footrest Bracket, Comp RH	
	1505219-16	Rear Footrest Bracket, Comp LH	

F-10 坐垫总成 SEAT ASSY



	15052110-1	Seat Assy	
	15052110-2	Side Cover Ornament RH	
	15052110-3	Side Cover, RH	
	15052110-4	Side Cover Ornament LH	
	15052110-5	Side Cover, LH	
	15052110-6	Rear Panel Set	
	15052110-7	Tool Kit	



	15052111-1	Fuel Tank Weldment	
	15052111-2	Fuel Tank Ornament, ON	
	15052111-3	Front Cushion, Fuel Tank	
	15052111-4	Fuel Sensor	
	15052111-5	Fuel Cock Comp.	
	15052111-6	Fuel Tank Rear Cushion	
	15052111-7	Lock Assy	
	15052111-8W	Fuel Tank Ornament, LH	
	15052111-9	Fuel Tank Inner Ornament, LH	
	15052111-10W	Fuel Tank Ornament, RH	
	15052111-11	Fuel Tank Inner Ornament, RH	

F-12 空气滤清器总成 AIR CLEANER ASSY



	15052112-1	Air Cleaner Assy	
	15052112-2	Air Clean Filter Set	
	15052112-3	Fuel/Vapor Separator	

F-13 排气消声器总成 EXHAUST MUFFLER ASSY



	15052113-1	Exhaust Muffler Comp.	
	15052113-2	Muffler Guard	
	15052113-3	Exhaust Muffler Gasket	

F-14 后叉焊接组合 链盒 REAR FORK & CHAINCASE



	15052114-1	Rear Fork Weldment	
	15052114-2	Rear Fork Shaft	
	15052114-3	Chain Guide	
	15052114-4	Chain 08MB×106	
	15052114-5	Rear Shock Absorber Rocker Comp.	
	15052114-6	Chaincase	
	15052114-7	Chain Adjuster Comp.	

F-15 后挡泥板 REAR FENDER



	15052115-1	Rear Fender Rear Body	
	15052115-2	Rear Fender Rear Bracket	
	15052115-3	Rear Fender Front Body	
	15052115-4	Rear Reflector	

F-16 车架总成 FRAME WELDMENT



	15052116-1	Frame Weldment	
	15052116-2	Lock Assy Stay Comp	
	15052116-3	Engine Front Suspension Plate	
	15052116-4	Fuel Tank Ornament Bracket	
	15052116-5	Seat Lock Cable	
	15052116-6	Seat Lock Set	
	15052116-7	Rear Handrail	

F-17 电器 ELECTRIC ELEMENTS



	15052117-1	Main Cable	
	15052117-2	Battery	
	15052117-3	Band, Battery	
	15052117-4	Horn	
	15052117-5	Flashing Relay	

157FMJ

Engine Parts

LF150-5U



UNIVERSAL
H A R D W A R E®


Box 585, Center Road
Spanish Lookout
Tel 501 823 0254
sales@universalhardware.bz

3380 Chetumal Street
Belize City
Tel 501 224 4140
salesbz@universalhardware.bz

E-01 气缸 气缸头 CYLINDER BLOCK & CYLINDER HEAD



	1575211-1	Set Pin (Φ10×12)	
	1575211-2	Gasket	
	1575211-3	Cylinder Block	
	1575211-4	Pad, cylinder head damping	
	1575211-5	Gasket	
	1575211-6	Cylinder Head Assy	
	1575211-7	Gasket, cylinder head	
	1575211-8	Spark Plug CR8E	
	1575211-9	Cap Nut	
	1575211-10	cylinder head Gasket	
	1575211-11	Gasket, cylinder head cover	
	1575211-12	Inlet Pipe Set	
	1575211-13	Set Pin (Φ8×14)	




	1575212-1	Lock Washer	
	1575212-2	Valve Stem Oil Seal	
	1575212-3	Seat, valve spring, lower	
	1575212-4	Valve Spring Upper Seat	
	1575212-5	Camshaft Assy	
	1575212-6	Support, rocker arm	
	1575212-7	Rocker Arm Assy	
	1575212-8	Valve Clamp	
	1575212-9	Intake Valve	
	1575212-10	Exhaust Valve	
	1575212-11	Valve Outer Spring	
	1575212-12	Valve Inner Spring	

E-03 正时链条 张紧装置 TIMING CHAIN & TENSINER



	1575213-1	Guide Plate	
	1575213-2	Tension Plate	
	1575213-3	Timing Chain	
	1575213-4	Tensioner	
	1575213-5	Tensioner Gasket	
	1575213-6	Driven Timing Sprocke	
	1575213-7	Plate, tensioner pressing	

E-04 右曲轴箱盖 RIGHT CRANKCASE COVER



	1575214-1	Set Pin (φ8×14)	
	1575214-2	Right Crankcase Cover	
	1575214-3	Gasket	
	1575214-4	Dipstick	
	1575214-5	O-Ring (φ18×3)	
	1575214-6	Operating Lever,Clutch	
	1575214-7	Oil Seal (φ12×22×5)	
	1575214-8	Spring	
	1575214-9	Glass, sight	

E-05 曲轴箱 CRANKCASE



	1575215-1	Stud	
	1575215-2	Left Crankcase	
	1575215-3	Set Pin (φ10×12)	
	1575215-4	Indicator, gear	
	1575215-5	O-ring	
	1575215-6	Right Crankcase	
	1575215-7	Oil seal	

E-06 机油泵 机油滤清器 OIL PUMP & OIL FILTER



	1575216-1	Primary Drive Gear	
	1575216-2	Oil Pump Assy	
	1575216-3	Gear, oil pump driven	
	1575216-4	Filter Assy	
	1575216-5	Nut	
	1575216-6	Thrust-Washer	
	1575216-7	Gauze set	

E-07 离合器 CLUTCH




	1575217-1	Washer, clutch	
	1575217-2	Clutch Body Assy	
	1575217-3	Push Rod	
	1575217-4	Bearing 16003	
	1575217-5	Clutch Driven Disc Assy	
	1575217-6	Bush, clutch	
	1575217-7	Thrust Washer	
	1575217-8	Drive Disc Comp	
	1575217-9	Tightening Nut	
	1575217-10	Clutch Drive Plate Comp	
	1575217-11	Clutch Driven Plate	

E-08 左曲轴箱盖 磁电机 LEFT CRANKCASE COVER & MAGNETO



	1575218-1	Left Crankcase Cover	
	1575218-2	Dowel Pin (Φ8×14)	
	1575218-3	O-Ring (Φ27.5×Φ2.5)	
	1575218-4	Left Crankcase Cover Gasket	
	1575218-5	Plug	
	1575218-6	Rotor With Starting Clutch	
	1575218-7	O-Ring (Φ13.8×Φ2.5)	
	1575218-8	Plug Watch Hole	
	1575218-9	Magneto Stator Assy	
	1575218-10	Washer, (φ14×28.2×3)	
	1575218-11	Lock nut, magneto, (M14×1.25)	
	1575218-12	Rear-Left Cover	

E-09 曲轴 活塞 CRANKSHAFT-PISTON



	1575219-1	Piston Pin	
	1575219-2	Retainer, $\phi 28$	
	1575219-3	Washer, I	
	1575219-4	Washer	
	1575219-5	Washer, II	
	1575219-6	Gear, balanced shaft driven	
	1575219-7	Rubbe	
	1575219-8	Plate, balanced driven gear	
	1575219-9	Spring, balanced shaft	
	1575219-10	Bearing, 6202	
	1575219-11	Shaft, balanced	
	1575219-12	Crankshaft Assy	
	1575219-13	Woodruff Key	
	1575219-14	Bearing	
	1575219-15	Gear, balanced shaft driven	
	1575219-16	Piston	
	1575219-17	Piston Ring Set	
	1575219-18	Circlip	

E-10 传动装置 TRANSMISSION DEVICE



	15752110-1	Countershaft Assy	
	15752110-2	Mainshaft Assy	
	15752110-3	Mainshaft	
	15752110-4	Countershaft	
	15752110-5	Washer II, countershaft	
	15752110-6	Countershaft First Gear	
	15752110-7	Countershaft Gear Bush	
	15752110-8	Countershaft Fourth Gear	
	15752110-9	Bush, countershaft gear	
	15752110-10	Gear, countershaft 3rd	
	15752110-11	Washer, countershaft inner spline	
	15752110-12	Circlip, countershaft	

	15752110-13	Washer I, countershaf	
	15752110-14	Gear, countershaft 5nd	
	15752110-15	Washer I, countershaf	
	15752110-16	Bush, countershaft gear	
	15752110-17	Gear, countershaft 2nd	
	15752110-18	Washer, main shaft	
	15752110-19	Mainshaft Second Gear	
	15752110-20	washer, spline, inner	
	15752110-21	Mainshaft Fifth Gear	
	15752110-22	Mainshaft Third Gear	
	15752110-23	washer, spline, inner	
	15752110-24	circlip, main shaft	
	15752110-25	Bush, countershaft gear	
	15752110-26	Mainshaft Fourth Gear	
	15752110-27	Output Sprocket	
	15752110-28	Oil Seal	
	15752110-29	Sprocket Locating Plate	
	15752110-30	Bearing 6204	
	15752110-31	Bearing, countershaft,	
	15752110-32	Bearing 6203	
	15752110-32	Bearing 6201RS	

E-11 变档机构 GEARSHIFT DEVICE



	15752111-1	Drum, gearshift	
	15752111-2	Wheel, gearshift	
	15752111-3	Shaft II, fork	
	15752111-4	Fork II	
	15752111-5	Shaft I, fork	
	15752111-6	Fork I	
	15752111-7	Shaft Assy, gearshift	
	15752111-8	Spring, locating plate	
	15752111-9	Plate set, gearshift locating	
	15752111-10	Washer, gearshift locating plate	
	15752111-11	Screw, gearshift locating plate	

E-12 起动电机STARTING MOTOR



	15752112-1	Gear set, starting clutch	
	15752112-2	Bearing, needle	
	15752112-3	Motor Assy, starting	
	15752112-4	Dual-gear	
	15752112-5	Shaft, dual-gear	

E-13 化油器 电器 CARBURETOR & ELECTRIC ELEMENTS


	15752113-1	Voltage Regulator	
	15752113-2	Ignition Controller	
	15752113-3	Ignition Coil	
	15752113-4	Start Relay	
	15752113-5	Carburetor Assy	

	15752114-1	Complete Gasket Set 157FMJ-SO2	
	15752114-2	Complete Bearing Set 157FMJ-SO2	
	15752114-3	Complete O Ring set 157FMJ-SO2	
	15752114-4	Complete Seal set 157FMJ-SO2	
	15752114-5	Complete Engine 157FMJ-SO2	



LIFAN Motorcycle Warranty Policy

AUGUST 2024 Edition

LIFAN Motorcycle are covered under a warranty for **6 months or 6,000 kms**, whichever comes first. The specific items under warranty include:

- ❖ **The Engine** and its related parts
- ❖ Any defects or issues resulting from **substandard manufacturing or assembly**.

Items Not Covered Under Warranty:

The following items are not covered under this warranty:

- ❖ Tires & tubes; chain & sprockets; oils; covers & mirrors
- ❖ Any damages or wear and tear resulting from the **owner's handling and maintenance** of the motorcycle

Important Reminders for Safe Riding and Maintenance:

- ✓ Always wear a **helmet** while riding.
- ✓ Always keep your **headlights on**, even during the day, for safety and to prolong battery life.
- ✓ Ensure all **lights** are always functioning properly.
- ✓ Ride with **insurance** and proper **licensing**.
- ✓ **Change the oil** after the first **500 kms** and then every **2,000 kms**.
- ✓ Use **SAE 15W-40 or 10W-40** motor oil.
- ✓ Use **REGULAR** gasoline for small engines like motorcycles, not premium.
- ✓ Regularly **tighten all screws**.
- ✓ Periodically adjust the **tightness of the chain**.
- ✓ Review the Owner's Manual for more details.
- ✓ **Drive safely** within speed limits and always, wear a **helmet**.

By following these guidelines, you can ensure your LIFAN motorcycle remains in good condition and continues to provide a safe and enjoyable riding experience.