

UNIVERSAL

H A R D W A R E[®]



MOTORCYCLE PARTS CATALOGUE

Model: **LF150T-12C**

Spanish Lookout

sales@universalhardware.bz

+501 823 0254 +501 652-9933

Belize City

salesbz@universalhardware.bz

+501 224-4140 +501 667-3937

2025



LIFAN



Model: **LF150-5U**



Model: **LF250GY-4**



Model: **ML125-16D Flash**



Model: **LF150-5L**



Model: **ML250GY-4**



Model: **ML200ZH-3**



Model: **ML200GY-4**



Model: **LF100-A**



Model: **LF110-7A NINJA**



Model: **LF200GY-4**



Model: **LF125-5**



Model: **LF125-7**



Model: **LF150T-12C**



Model: **LF150-7 Retro**



Model: **LF200-14F**

F-01 方向把 STEERING BAR


150121-1	Handlebar Pipe Hood LH	
150121-2	Handlebar Pipe Hood RH	
150121-3	Steering bar Pipe Hood Bracket LH	
150121-4	Steering bar Pipe Hood Bracket RH	
150121-5	Grip Comp.,LH	
150121-6	Throttle Grip Comp.	
150121-7	Handlebar Switch,LH	
150121-8	Handlebar Switch,RH	
150121-9	Rearview Mirror,LH	
150121-10	Rearview Mirror,RH	
150121-11	Steering bar	
150121-12	Lever, rear brake	
150121-13	Lever, rear brake Assy	
150121-14	Steering Bar Holder	
150121-15	Steering Bar Seat	
150121-16	Rear Brake Cable	

F-02 仪表总成 METER ASSY



150122-1	Meter Assy
150122-2	Odometer Cable Comp.
150122-3	Front Windshield
150122-4	Windshield bracket



150123-1	Headlight Hu Gang
150123-2	Headlight Pipe Hood
150123-3	Headlight Assy Stay Comp
150123-4	Parking Light
150123-5	Headlight Assy
150123-6BU	Front Cover - Blue
150123-6R	Front Cover - Red
150123-7	Front and right lighting
150123-8	Front and left decorative lights
150123-9	Headlight left press
150123-10	Headlight right press

F-04 车架中部覆盖件 FRAME MID COVER



150124-1	Front Trunk Clamp	
150124-2	Guard, lower	
150124-3	Rear Luggage Front Hood	
150124-4	Front Trunk Lining LH	
150124-5	Helmet Hook	
150124-6	Front Trunk	
150124-7	VIN Cover Plate	
150124-8	Rider Treadle	
150124-9	Battery Case Cover	



150125-1BU	Side Cover,RH - Blue
150125-1R	Side Cover,RH - Red
150125-2BU	Side Cover,LH - Blue
150125-2R	Side Cover,LH - Red
150125-3	Rear Carrier

F-6 后置物箱 REAR LUGGAGE




150126-1	Seat Assy	
150126-2	Rear Luggage	
150126-3	Tool Kit	

F-07 前挡泥板 FRONT FENDER




150127-1BU	Front Fender - Blue	
150127-1R	Front Fender - Red	



150128-1	Front Winker,RH	
150128-2	Rear Fender Front Body	
150128-3	Front Winker,LH	
150128-4	Rear Fender Connecting Plate	
150128-5	Taillight Assy	
150128-6	Side Reflector	
150128-7	Rear Fender	
150128-8	Side Reflector	
150128-9	Rear Winker, RH	
150128-10	Rear Winker, LH	
150128-11	Rear Reflector	
150128-12	Bulb 12v/10w	
150128-13	Rear License Bracket	

F-09 前叉 FRONT FORK



150129-1	Steering Stem	
150129-2	Adjusting Bearing	
150129-3	Front Shock Absorber,LH	
150129-4	Front Shock Absorber,RH	
150129-5	Odometer Cable Clip	

F-10 前液压制动器 FRONT HYDRAULIC BRAKE ASSY



1501210-1	Front Hydraulic Brake Assy	
1501210-2	Front Brake Lever	
1501210-3	Front Brake Switch	
1501210-4	Front Brake Pad	
1501210-5	Rear Brake Oil Pipe Circlip	

F-11 前轮 FRONT WHEEL



1501211-1	Front Tyre	
1501211-2	Speedometer Gear Box	
1501211-3	Front Wheel Hub Comp.	
1501211-4	Front Brake Disc	
1501211-5	Tube Valve	
1501211-6	Front Axle	
1501211-7	Front Wheel Bush LH	
1501211-8	Nut	

F-12 后轮 REAR WHEEL


1501212-1	Rear Tyre	
1501212-2	Tube Valve	
1501212-3	Rear Wheel Hub Comp.	
1501212-4	Rear Wheel Bush, RH	
1501212-5	Rear Axle Right Bush	
1501212-6	Rear Brake Shoe Set	
1501212-7	Connecting Plate Comp, Rear Absorber	
1501212-8	Rear Fender Bracket, LH	
1501212-9	Rear Fender Bracket, RH	

F-13 后减震器总成 REAR SHOCK ABSORBER ASSY



1501213-1	Rear Shock Absorber Assy	
-----------	--------------------------	--

F-14 油箱 FUEL TANK ASSY



1501214-1	Fuel Sensor	
1501214-2	Fuel Tank Weldment	
1501214-3	Vacuum Switch	
1501214-4	Fuel Filler Cover Set	
1501214-5	Hose	
1501214-6	Hose	
1501214-7	Hose	
1501214-8	Fuel Filter Comp.	

F-15 消声器总成 EXHAUST MUFFLER ASSY



1501215-1	Exhaust Muffler Comp.	
1501215-2	Muffler Ornament	
1501215-3	Exhaust Muffler Gasket	

F-16 空气滤清器总成 AIR CLEANER ASSY



1501216-1	Air Cleaner Assy	
1501216-2	Air Clean Filter Set	

F-17 车架 FRAME



1501217-1	Frame Weldment	
1501217-2	Rubber	
1501217-3	Engine Suspension Comp.	
1501217-4	Axle Of Engine	
1501217-5	Back fender bracket	

F-18 主、侧支架 CENTER & SIDE STAND




1501218-1	Side Stand Bolt	
1501218-2	Side Stand	
1501218-3	Side Stand Spring	
1501218-4	Bush Center Stand	
1501218-5	Center Stand Comp.	
1501218-6	Center Stand Spring	
1501218-7	Bush Center Stand	
1501218-8	Rubber Center Stand	

F-19 电器件 ELECTRIC ELEMENT



1501219-1	Ignition Controller	
1501219-2	Starting Relay	
1501219-3	Voltage Regulator	
1501219-4	Ignition Coil	
1501219-5	Main Cable	
1501219-6	Flashing Relay	
1501219-7	Horn	
1501219-8	Battery	

LF150T-12 F-20 锁具总成 LOCK ASSY



1501220-1	Lock Assy	
1501220-2	Seat Lock Cable	
1501220-3	Throttle Cable	

157QMJ

Engine Parts

LF150T-12C




UNIVERSAL

H A R D W A R E®

Box 585, Center Road
Spanish Lookout
Tel 501 823 0254
sales@universalhardware.bz


3380 Chetumal Street
Belize City
Tel 501 224 4140
salesbz@universalhardware.bz

E-1 风扇盖 磁电机 FAN COVER & MAGNETO




157121-1	Magneto Assy	
157121-2	Magneto Rotor Comp.	
157121-3	Magneto Stator Comp.	
157121-4	Bolt M6x25	
157121-5	Bolt M5x12	
157121-6	Washer 12	
157121-7	Nut M12x1.25	
157121-8	Fan Impeller	
157121-9	Bolt M6x18	
157121-10	Cooling Fan Cover	
157121-11	Air-Flow Guard B	
157121-12	Bolt M6x25	
157121-13	Screw ST4.8x16	
157121-14	Starter Motor Wire Clamper	
157121-15	Bolt M6x25	
157121-16	Overflow Pipe Clamp	
157121-17	Air-Flow Guard A	

E-2 气缸头盖 CYLINDER HEAD COVER




157122-1	Cylinder Head Cover	
157122-2	Waste Pipe	
157122-3	Waste Pipe Clip $\phi 8$	
157122-4	Cylinder Head Cover Gasket	
157122-5	Bolt M6x25	
157122-6	Plate	
157122-7	Screw M4x8	
157122-8	Exhaust Nipple	
157122-9	Washer 6.5	
157122-10	Bolt M6x12	




157123-1	Cylinder Head
157123-2	Stud M6x32
157123-3	Stud M6x62
157123-4	Bolt M6x100
157123-5	Dowel Pin 10×14
157123-6	Valve Split Cone
157123-7	Valve Spring Upper Seat
157123-8	Valve Inner Spring
157123-9	Valve Outer Spring
157123-10	Valve Lower Seat
157123-11	Valve Stem Oil Seal
157123-12	Exhaust Valve
157123-13	Inlet Valve
157123-14	Gasket for Cylinder Head
157123-15	Spark Plug A7RTC
157123-16	Inlet Pipe Casket
157123-17	Isolating Mat
157123-18	O-Ring 28×2.5
157123-19	Inlet Pipe Set
157123-20	Nut M6
157123-21	Inlet Pipe Clip
157123-22	Guide O-Ring
157123-23	Inlet Valve Guide
157123-24	Exhaust Valve Guide

E-4 凸轮 摇臂 DRUM & ROCKET ARMY




157124-1	Cylinder Block Dowel Pin 10×14
157124-2	Washer 8
157124-3	Nut M8
157124-4	Rocker Arm Base
157124-5	Caging Plate
157124-6	Rocker Arm Shaft Set
157124-7	Rocker Arm Shaft
157124-8	Valve Rocker Arm
157124-9	Valve Clearance Adjusting Nut
157124-10	Valve Clearance Adjusting Screw
157124-11	Camshaft Assy
157124-12	Rocker Arm Assy
157124-13	Camshaft Fix Assy

E-5 气缸体 活塞 曲轴 CYLINDER PISTON & CRANKSHAFT




157125-1	Timing Chain
157125-2	Tensioning Plate
157125-3	Guide Plate
157125-4	Tensioning Plate Screw
157125-5	O-Ring 15.2x1.5
157125-6	Cylinder Block Comp.
157125-7	Piston Ring II
157125-8	3-piece Oil Ring
157125-9	Cylinder Block Gasket
157125-10	Cylinder Block Dowel Pin 10×14
157125-11	Piston
157125-12	Piston Pin
157125-13	Piston Pin Circlip
157125-14	Piston Ring Set
157125-15	Crankshaft and Connecting Rod
157125-16	Woodruff Key 25x14x4
157125-17	Tensioner
157125-18	Tensioner Gasket
157125-19	Bolt M6x22
157125-20	O-Ring 1.5x9.5
157125-21	Screw M6x6
157125-22	Tensioner Assy
157125-23	Piston Ring I

E-6 右曲轴箱盖 RIGHT CRANKCASE COVER




157126-1	Crankcase Cover, RH
157126-2	Crankshaft Oil Seal,RH 9.8x30x5
157126-3	Crankcase Cover Gasket, RH
157126-4	Dipstick
157126-5	O-Ring
157126-6	Oil Filter Screen
157126-7	Oil Filter Screen Spring
157126-8	Oil Filter Screen Cover O-Ring
157126-9	Oil Filter Screen Cover
157126-10	Magneto Wire Clamper
157126-11	Bolt M6x110
157126-12	Bolt M6x100
157126-13	Bolt M6x95
157126-14	Bolt M6x28
157126-15	Bolt M6x32
157126-16	Dowel Pin 8x14
157126-17	Dipstick

E-7 机油泵 OIL PUMP



157127-1	Oil Pump Assy	
157127-2	Oil Pump Shaft	
157127-3	Oil Pump Body	
157127-4	Dowel Pin 4x6.5.	
157127-5	Oil Pump Outer Rotor	
157127-6	Oil Pump Inner Rotor	
157127-7	Oil Pump Cover	
157127-8	Bolt M3x10	
157127-9	Bolt M6x25	
157127-10	Oil Pump Driven Sprocket	
157127-11	Nut M6	
157127-12	Oil Pump Chain	
157127-13	Driven Sprocket Stopper	
157127-14	Bolt M6x12	

E-8 启动电机 STARTER MOTOR




157128-1	Start Motor Wiring Harness	
157128-2	Start Motor	
157128-3	Twin-Gear	
157128-4	twin-Gear Shaft	
157128-5	Start Clutch Gear	
157128-6	Needle Bearing K28x32x17	
157128-7	Socket Bolt M6x10	
157128-8	Starting Clutch Body Comp.	
157128-9	Roller 10x10	
157128-10	Starting Clutch Spring	
157128-11	Starting Clutch Spring Sleeve	
157128-12	Starting Clutch Cover	
157128-13	Starting Clutch Gear Washer	
157128-14	Lock Nut M22	
157128-15	Start Clutch Assy	

E-9 曲轴箱 CRANKCASE




157129-1	Crankcase, RH	
157129-2	Engine Hanger Bush	
157129-3	Bolt M6x50.	
157129-4	Dowel Pin 8x14	
157129-5	Cylinder Stud A	
157129-6	Crankcase Gasket	
157129-7	Crankcase Comp., LH	
157129-8	Rear Shock Absorber Lower Bush	
157129-9	Crankshaft Oil Seal,LH 19.8x30x5	
157129-10	Bearing 6301	
157129-11	Bearing 6002	
157129-12	Bearing 6004DU	
157129-13	Oil Seal 27x42x7	
157129-14	Cylinder Stud B	
157129-15	Drain Plug Washer	
157129-16	Plug	
157129-17	Waste Pipe Set	
157129-18	Brake Shoe Pin	
157129-19	Nut M8	
157129-20	O-Ring 7.5x1.5	

E-10 左曲轴箱盖LEFT CRANKCASE COVER




1571210-1	Stopper	
1571210-2	Bolt M6x12	
1571210-3	Bush 12x16x12	
1571210-4	Special Pin 4.5	
1571210-5	Starting Shaft	
1571210-6	Starting Return Spring	
1571210-7	Starting Shaft Washer 14	
1571210-8	Bush	
1571210-9	Starting Shaft Assy	
1571210-10	Starting Mid-Gear Comp.	
1571210-11	Kick Starter Assy	
1571210-12	Crankcase cover Gasket, LH	
1571210-13	Guide Plate	
1571210-14	Screw ST4x8	
1571210-15	Crankcase Cover, LH	
1571210-16	Dowel Pin 8x14	
1571210-17	Bolt M6x40	
1571210-18	Bolt M6x65	
1571210-19	Cable Clamp	
1571210-20	Main Stand Stopper	
1571210-21	Bolt M6x12	
1571210-22	Brake Cable Clamp	
1571210-23	Bolt M6x22	

E-11 从动轮 DRIVEN PULLEY




1571211-1	Driven Pulley Comp.	
1571211-2	Driven Disc Comp.	
1571211-3	Driven Pulley Assy	
1571211-4	Washer12.2x29x2.5	
1571211-5	Nut M12	

E-12 皮带 主动轮 BELT DRIVING




1571212-1	Drive Belt (L=723)	
1571212-2	Starting Driven Gear (20T)	
1571212-3	Drive Gear Sleeve	
1571212-4	Driving Pulley Sliding Plate	
1571212-5	Centrifugal Roller Set	
1571212-6	Drive Gear Chuck	
1571212-7	Drive Gear Chuck Slide-Block	
1571212-8	Driving Pulley Fixing Plate	
1571212-9	Washer 12.2x29x2.5	
1571212-10	Lock Nut M12	
1571212-11	Driving Pulley Assy	

E-13 传动系 TRANSMISSION SYSTEM




1571213-1	Transmission Case	
1571213-2	Bearing 6204	
1571213-3	Bearing 6202	
1571213-4	Bearing 6203	
1571213-5	Oil Seal 20x32x6	
1571213-6	Washer 8	
1571213-7	Bolt M8x12	
1571213-8	Bolt M8x12	
1571213-9	Bolt M6x28	
1571213-10	Bolt M6x35	
1571213-11	Gasket	
1571213-12	Dowel Pin 8x14	
1571213-13	Drive Shaft	
1571213-14	Mid Shaft Assy	
1571213-15	Output Shaft	
1571213-16	Spring Circlip	
1571213-17	Terminal Gear	
1571213-18	Output Shaft Set	

E-14 化油器 CARBURETOR




1571214-1	Carburetor Assy	
-----------	-----------------	--

E-16 全套纸垫 A FULL SET OF GASKETS


**1571216-1****A Full Sets Of Gasket**

E-17 全套密封圈 A FULL SET OF O-RINGS




1571217-1	A Full Sets Of O-Rings
-----------	------------------------

E-18 全套油封 A FULL SET OF OIL SEAL



1571218-1	A Full Sets Of Oil Seals
-----------	--------------------------

A FULL SET OF BEARINGS



1571219-1

A Full Sets Of Bearings

157QMJ

LF150T-12C



157QMJ

Complete Engine 157QMJ



LIFAN Motorcycle Warranty Policy

AUGUST 2024 Edition

LIFAN Motorcycle are covered under a warranty for **6 months or 6,000 kms**, whichever comes first. The specific items under warranty include:

- ❖ **The Engine** and its related parts
- ❖ Any defects or issues resulting from **substandard manufacturing or assembly**.

Items Not Covered Under Warranty:

The following items are not covered under this warranty:

- ❖ Tires & tubes; chain & sprockets; oils; covers & mirrors
- ❖ Any damages or wear and tear resulting from the **owner's handling and maintenance** of the motorcycle

Important Reminders for Safe Riding and Maintenance:

- ✓ Always wear a **helmet** while riding.
- ✓ Always keep your **headlights on**, even during the day, for safety and to prolong battery life.
- ✓ Ensure all **lights** are always functioning properly.
- ✓ Ride with **insurance** and proper **licensing**.
- ✓ **Change the oil** after the first **500 kms** and then every **2,000 kms**.
- ✓ Use **SAE 15W-40 or 10W-40** motor oil.
- ✓ Use **REGULAR** gasoline for small engines like motorcycles, not premium.
- ✓ Regularly **tighten all screws**.
- ✓ Periodically adjust the **tightness of the chain**.
- ✓ Review the Owner's Manual for more details.
- ✓ **Drive safely** within speed limits and always, wear a **helmet**.

By following these guidelines, you can ensure your LIFAN motorcycle remains in good condition and continues to provide a safe and enjoyable riding experience.