






1	099992201602	Gear Case Assembly	
25	099992201603	Boom Assembly, Sliver	
28	099992201122	Solid Drive Shaft	
30	099992201604	Holder Assembly	
73	099992201610	Large String Head Assembly	




24	099992201119	HS-Blade	
35	099992201605	Clutch Assembly	
36	099992201128	Clutch Case	
38	099992201130	Bearing 6202-2RS/P5	
40	099992201132	Connector	
47	099992201139	Boom Cushion	
85	099992201174	Blade Guard, Black	




49	099992201141	Bolt M6x25	
50	099992201142	Holder, Lower	
51	099992201143	Rubber Washer	
52	099992201144	Bracket	
53	099992201145	Bike Handle	
54	099992201146	Rubber Grip	
55	099992201147	Holder ,Upper	
56	099992201148	Bolt M5x25	
57	099992201149	Rubber Grip Housing	
58	099992201606	Operating Lever Assembly	

Trimmer


HBC45SB & HBC52SB




1	099992201001	Screw M5x12-9.8-DZ	
2	099992201002	Starter Pulley	
3	099992201003	Starter Rope Wheel	
4	099992201004	Rope	
5	099992201005	Recoil Spring	
6	099992201006	Starter Cover Assembly	
7	099992201007	Starter Grip, Yellow	
8	099992201096	Fire Label, Flexcon	
9	099992201008	Small Spring	
10	099992201009	Holder Pin	
11	099992201600	Starter Assembly, Black	
12	099992201010	Rubber Mat	
14	099992201012	Screw M5x20	
16	099992201014	Starter Gasket	
17	099992201015	Starter Reel	
18	099992201016	Oil Seal	
19	099992201017	Rear Half Crankcase	
20	099992201018	Gasket	
21	099992201019	Bearing 6202/P5	




22	099992201020	Crank Shaft	
23	099992201021	Key 3x13	
24	099992201022	Pin B5x12	
25	099992201023	Rubber Washer	
26	099992201024	Front Half Crankcase	
27	099992201025	Guide Cover	
28	099992201026	Pin B4x10	
29	099992201027	Oil Seal	
30	099992201028	Screw M5x30	
31	099992201029	Fly Wheel	
32	099992201030	Nut M8	
33	099992201031	Magneto	
34	099992201032	Bolt M5x20	
35	099992201033	Cord Assembly	
36	099992201034	Washer B	
37	099992201035	Spring	
38	099992201036	Clutch Assembly	
39	099992201037	Washer	
40	099992201038	Screw Pin	



41	099992201039	Fly Wheel Cover	
42	099992201040	Screw M5x25	
43	099992201041	Pin Bearing	
44	099992201042	Stop Ring	
45	099992201043	Piston	
46	099992201044	Piston Pin	
47	099992201045	Bolt M5x25	
48	099992201046	Piston Ring	
49	099992201047	Gasket	
50	099992201048	Cylinder	
51	099992201049	Screw M5x20	
52	099992301002	Cylinder House, Gray	
53	099992201051	Spark Plug	
54	099992201192	Plug Cap	
55	099992201053	Screw M5x20	
57	099992201055	Housing Upper Cover, Black	
58	099992201056	Rubber Eyelet 2	
59	099992201057	Gasket	
60	099992201058	Muffler	
61	099992201059	Bolt	
62	099992201060	Nut M6	



63	099992201061	Muffler Cover	
64	099992201062	Gasket	
65	099992201063	Heat Dam	
66	099992201064	Gasket	
67	099992201182	Carburetor	
68	099992201066	Screw ST2.9x6.5	
69	099992201067	Washer 3	
70	099992201068	Choke Lever, Yellow	
71	099992201069	Filter Box	
72	099992201070	Choke	
73	099992201071	Stator	
74	099992201072	Washer 5	
75	099992201073	Washer 5	
76	099992201074	Screw M5x55	
77	099992201075	Filter	
78	099992201076	Inner Cover	
79	099992201077	O-Washer 3.15x1.8	
80	099992201078	Filter Box Cover, Black	
81	099992201079	Screw M5x16	
82	099992201080	Sound Level Label, Flexcon	



83	099992201081	Fuel Filter	
84	099992201082	Fuel Pipe (meter), yellow	
85	099992201083	Rubber Plug	
86	099992201084	Fuel Pipe (meter), black	
87	099992201085	Fuel Tank, Milk White	
88	099992201086	Fuel Tank Cap, Black	
89	099992201087	Gasket	
90	099992201088	Air Inlet	
91	099992201089	Inner Cover	
92	099992201090	Chain Connector	
93	099992201091	Chain	
94	099992201601	Fuel Tank Lid Assembly	
95	099992201183	Metal Engine Stand	
96	099992201093	Screw M5x30	
97	099992301004	Logo Label, PET	
98	099992201095	Hot Surface Label, Flexcon	
99	099992201096	Fire Label, Flexcon	